

# Technology Instructions

## with Wall Panel Controls

### Graduate Center

**For basic use, use "Presentation Mode"**  
(DISTANCE LEARNING MODE is for distance learning events with another classroom.)

#### **TROUBLESHOOTING:**

**If computer is locked, restart.** If you log in to access your H drive, LOG OFF, or computer will lock.

The small light on the bottom right corner of the small overlay SmartBoard indicates connectivity with computer. It IS NOT necessary to use the overlay to project.

If **solid green**, connection is good

If **blinking green**, connection may be intermittent. Re-start computer

If **solid orange**, connection is off. Re-start computer

If no light, connection is off. Re-start computer

To use one projector and one whiteboard to write on, you must use ADVANCED MODE

#### **BASIC PRESENTATION MODE**

##### **1. To Start**

**Touch screen of wall panel.**

**Touch Lincoln seal.** System will power up in 15 seconds

**Tap "PRESENTATION"**

##### **2. Note:** inputs for projection are on left side of wall panel as follows:

PC, Laptop, DVD/BluRay Player, DocCamera

**Select input.** When an input is selected, all 3 large projection screens will power up. This takes 3-5 minutes.

##### **3. Using with Computer**

**Turn on computer or attach laptop** at instructor's podium.

If using the computer/laptop, you may select ANNOTATION on the wall panel to use the small overlay SmartBoard behind instructor's podium and Notebook software.

Log in as "guest," no password

If accessing "H" drive, use personal log-in and LOG OFF after class

##### **4. Adjust volume** on computer and at wall panel.

##### **5. To Shut Down**

**Tap the "X"** in upper right corner of wall panel. **Tap "X"** again and **tap "YES"**

When finished, **if you logged in, LOG OFF**

### **ADVANCED PRESENTATION MODE**

Allows instructor to control all screens and annotation overlay independently.

#### **1. To Start**

**Touch screen of wall panel.**

**Touch Lincoln seal.** System will power up in 15 seconds

**Tap "PRESENTATION"**

**Tap "ADVANCED"** button at bottom of wall panel

**Tap "ADVANCED" in middle of screen**

**Tap input** on left of wall panel and **tap where to project** from selection on right side of wall panel.

#### **2. To Shut Down**

**Tap the "X"** in upper right corner of wall panel. **Tap "X"** again and **tap "YES"**

When finished, **if you logged in, LOG OFF**

### **TO SHOW DVD/BLURAY**

Use computer's DVD player and application called "Power DVD" or use BluRay Player

Adjust volume at wall plate

**FOR LIVE DISTANCE LEARNING, contact  
Academic Technology Support Center, 484-365-7355**