

SMART Board Basic Instructions

for Rooms with Epson Projector Remote

Graduate Center

1. To Start:

Turn on computer and SMART Board

SMART Board starts automatically with computer

Log in as "guest," no password

Turn on projector with Epson remote

Allow 3-5 minutes for projector to warm up

To Connect SMART Board with SB remote

If not highlighted, choose "Computer 1" using arrows and ENTER key

You should see the computer desktop

Use computer keyboard and mouse or use SMART Board as touch-screen monitor

For SMART Board features, use "Notebook" software

2. To Use Projection:

PowerPoint:

Access presentation using computer or using SMART Board as touch-screen monitor

DVD:

Use computer's DVD player, called Power DVD

Adjust volume with EPSON remote.

Knobs on speakers should be set at 12:00

3. When Finished:

Do not turn off computer or projector unless you are the last instructor of the day.

Then, turn off projector with EPSON remote and computer as you normally would. SMART Board will turn off with computer.

NOTE: Small rectangular light on bottom right of SMART Board indicates connectivity with computer. If solid green, connection is good. If blinking green, connection may be intermittent. If solid orange, connection is off: Restart computer.

Questions, Concerns, Additional Training

Call Academic Technology Support, Ext 7355