

SMART Board Basic Instructions

with Epson Projector Remote

UH Rm. 205

If computer is locked, restart.
If you log in to access your H drive, LOG OFF, or computer will lock.

1. To Start:

Turn on computer and SMART Board

SMART Board starts automatically with computer

Log in as "guest," no password

If accessing "H" drive, use personal log-in and LOG OFF after class

Turn on projector with Epson remote

Allow 3-5 minutes for projector to warm up

To Connect SMART Board

If not highlighted, choose "Computer 1" using arrows and ENTER key

You should see the computer desktop

Use computer keyboard and mouse or use SMART Board as touch-screen monitor

For SMART Board features, use "Notebook" software

2. To Use Projection:

PowerPoint:

Access presentation using computer or using SMART Board as touch-screen monitor

DVD:

Use computer's DVD player, called Power DVD

Adjust volume with EPSON remote

3. When Finished:

If you logged in, LOG OFF

Do not turn off computer or projector unless you are the last instructor of the day.

Then, turn off projector with EPSON remote and computer as you normally would. SMART Board will turn off with computer.

NOTE: Small rectangular light on bottom right of SMART Board indicates connectivity with computer. If solid green, connection is good. If blinking green, connection may be intermittent. If solid orange, connection is off: Restart computer.

Questions, Concerns, Additional Training

Call Academic Technology Support, Ext 7355